

OptionLock Installation Instructions



Insert the patented locking strip horizontally into the top section of the 2nd diamond down from the top of your chain link fence.



Insert the slats vertically until the patented notch snaps itself into the locking strip.



Enjoy your privacy!