
INSTALLATION INSTRUCTIONS

(Suggested installation instructions. Instructions vary per job site conditions)



Insert slats diagonally and lock them securely into place.

ALUMINUM SLAT SPECIFICATIONS

| SLAT NAME | SLAT WIDTH | MESH SIZE | WIRE GAUGE | COVERAGE AREA |
|-----------------|---------------|--------------|---------------|-------------------|
| ALUMINUM 2" | 1 7/8" | 2" | 9 OR 11 | 10 LINEAR FEET |
| ALUMINUM 2 1/4" | 2" | 2 1/4" | 11 1/2 OR 12 | 10 LINEAR FEET |

Aluminum Fence Slats